

Formatting SD card in Digital Concepts 2.1 MP Camera

Notes:

Formatting the cards-- if it does not start automatically.(C2 Error)

Put SD Card in camera

Turn Power Button ON

Hit the Shutter Button several times.

Earnhardtfanatic