

Sony settings for cam:
P32 P41
Cameras

Date time....on

Red eye reduction....off

AF illuminator....off

power save.....off

Beep.....off

Focus is set to infinity

Iso is forced to 400

Pic quality is set to fine

flash level is set at High

leave the camera on program setting

Hope this helps out